

**SPLIT TAILGATE
ASSEMBLY INSTRUCTIONS**

STEP ONE

Place loaded pallet at the rear side of the chute or palpation cage.



STEP TWO

Remove the tailgate stop bolt, and the rope and pulley assembly from the chute or palpation cage.



STEP THREE

Remove the tailgate from the chute or palpation cage.



STEP FOUR

Remove all banding and plastic ties. Remove split tailgate assembly from pallet. Then remove the two assembly bolts in the handle attachment brackets of the split tailgate.



STEP FIVE

Place the holding arm assembly on top of the chute. *Note: The holding arm bracket must be at least 19" from the squeeze chute actuator handle.*



STEP SIX

Attach two handle assembly bolts in the slots allotted.*



STEP SEVEN

Stand the split tailgate upright behind the chute or palpation cage. Place split tailgate corral hardware on top of palpation cage or chute hardware.



STEP EIGHT

Place the 63" attachment rod through both hookups on both sides of the split tailgate.



STEP NINE

Loosen the bolts on the telescoping tube.



STEP TEN

Extend the telescoping tube into the rear socket till it stops.



STEP ELEVEN

Tighten bolts in telescoping tube and rear socket with a crescent or socket wrench.*



STEP TWELVE

Tighten bolts in the handle assembly.*

Note: Do not over tighten bolt on operator side to allow free movement of the actuator with squeezing.



TIP

Insure handle is in locked position when the gate is closed.



INSTALLAION IS NOW COMPLETE



*Use bolts and nylon lock-nuts provided.

TARTER
FARM AND RANCH EQUIPMENT

WWW.TARTERFARMANDRANCH.COM